

ChatBot Aulas 11 e 12

Prof. Me Daniel Vieira



Agenda

- 1 Criando API com LLM integrada
- 2 FastAPI
- 3 Estrutura do projeto
- 4 Testes com Insomnia

Estrutura do projeto API com Chatbot

```
import os
from typing import List
from llama index.core import SimpleDirectoryReader, StorageContext,
VectorStoreIndex
from llama index.core.node parser import SentenceSplitter
from llama index.embeddings.huggingface import HuggingFaceEmbedding
from llama index.vector stores.chroma import ChromaVectorStore
from llama index.llms.groq import Groq
from llama index.core.memory import ChatSummaryMemoryBuffer
import chromadb
from tempfile import TemporaryDirectory
from PyPDF2 import PdfReader
```

```
class ChromaEmbeddingWrapper:
    def    init (self, model name: str):
        self.model = HuggingFaceEmbedding(model name=model name)

    def    call (self, input: List[str]) -> List[List[float]]:
        return self.model.embed documents(input)
```

```
class SerenattoBot:
    def
         init
                (self):
        self.embed model =
HuggingFaceEmbedding(model name='intfloat/multilingual-e5-large')
        self.embed model chroma =
ChromaEmbeddingWrapper(model name='intfloat/multilingual-e5-large')
        chroma client = chromadb.PersistentClient(path='./chroma db')
        collection name = 'documentos serenatto'
        chroma collection = chroma client.get or create collection(
            name=collection name,
            embedding function=self.embed model chroma
```

```
self.vector store = ChromaVectorStore(chroma collection=chroma collection)
        self.storage context =
StorageContext.from defaults(vector store=self.vector store)
        self.llms = Groq(model='llama3-70b-8192',
api key='qsk D6qheWgXIaQ5j13Pu8LNWGdyb3FYJXU0RvNNoIpEKV1NreqLAFnf')
        self.document index = None
        self.chat engine = None
        self.carregar pdf()
```

```
def carregar pdf(self):
    with TemporaryDirectory() as tmpdir:
        pdf path = "documentos/serenatto.pdf"
        text = ""
        reader = PdfReader(pdf path)
        for page in reader.pages:
        text += page.extract text() or ""
```

```
with open (os.path.join(tmpdir, "temp.txt"), "w", encoding="utf-8") as f:
                f.write(text)
            documentos = SimpleDirectoryReader(input dir=tmpdir)
            docs = documentos.load data()
            node parser = SentenceSplitter(chunk size=1200)
            nodes = node parser.get nodes from documents(docs)
            self.document index = VectorStoreIndex(nodes,
storage context=self.storage context, embed model=self.embed model)
```

main.py

```
from fastapi import FastAPI, Body
from pydantic import BaseModel
from serenatto bot import SerenattoBot

app = FastAPI(title="Serenatto Chatbot API")

# Instancia o bot na inicialização
bot = SerenattoBot()
```

main.py

```
class MensagemRequest(BaseModel):
    mensagem: str
class MensagemResponse(BaseModel):
    resposta: str
@app.post("/conversar", response model=MensagemResponse)
def conversar(request: MensagemRequest):
    resposta = bot.responder(request.mensagem)
    return MensagemResponse(resposta=resposta)
@app.post("/resetar")
def resetar():
    bot.resetar()
    return {"status": "Chat resetado com sucesso"}
```

main.py

```
class MensagemRequest(BaseModel):
    mensagem: str
class MensagemResponse(BaseModel):
    resposta: str
@app.post("/conversar", response model=MensagemResponse)
def conversar(request: MensagemRequest):
    resposta = bot.responder(request.mensagem)
    return MensagemResponse(resposta=resposta)
@app.post("/resetar")
def resetar():
    bot.resetar()
    return {"status": "Chat resetado com sucesso"}
```

Requirements.txt

fastapi

uvicorn

llama-index

PyPDF2

chromadb

transformers

huggingface hub

Comando para executar a api

uvicorn main:app -reload

```
PS D:\SENAI\2025-1\ChatBot\chatbot api> uvicorn main:app --reload
>>
          Will watch for changes in these directories: ['D:\\SENAI\\2025-1\\ChatBot\\chatbot api']
INFO:
INFO:
          Uvicorn running on http://127.0.0.1:8000 (Press CTRL+C to quit)
TNFO:
          Started reloader process [720] using WatchFiles
INFO:
          Started server process [17540]
INFO:
          Waiting for application startup.
TNFO:
          Application startup complete.
INFO:
          127.0.0.1:58451 - "POST /conversar HTTP/1.1" 200 OK
TNFO:
          127.0.0.1:58457 - "GET /docs HTTP/1.1" 200 OK
INFO:
          127.0.0.1:58457 - "GET /openapi.json HTTP/1.1" 200 OK
TNFO:
          127.0.0.1:58477 - "POST /conversar HTTP/1.1" 200 OK
INFO:
          127.0.0.1:58526 - "POST /conversar HTTP/1.1" 200 OK
INFO:
          127.0.0.1:58733 - "POST /conversar HTTP/1.1" 200 OK
INFO:
          127.0.0.1:58763 - "POST /conversar HTTP/1.1" 200 OK
INFO:
          127.0.0.1:58771 - "POST /conversar HTTP/1.1" 200 OK
```


FastApi

Code


Description




Links




Clicar em create a request collection




Clicar em create a request collection




Clicar em New HTTP request





O método http escolher o método post e utilizar o ip http://127.0.0.1:8000/conversar





O método http escolher o método post e utilizar o ip http://127.0.0.1:8000/conversar














2. Você está testando em um celular ou emulador?

- Emulador Android: use http://10.0.2.2:8000
- Celular físico: use o IP local da sua máquina, exemplo: http://192.168.0.108:8000 ♀ Você pode descobrir seu IP local com:

```
ipconfig (Windows)
ifconfig (Linux/Mac)
```

3. Você permitiu conexões externas no FastAPI?

Por padrão, o uvicorn escuta apenas 127.0.0.1.


→ Para permitir conexões do celular ou emulador, use:

```
uvicorn main:app --host 0.0.0.0 --port 8000 --reload
```

2. Assim que terminar, rode o comando:

3. Testa no Insomnia ou no navegador em http://localhost:8000/docs.

PROBLEMS 1 OUTPUT TERMINAL PORTS	ESP-IDF	MEMORY XRTOS	SERIAL MONITOR	DEBUG CONSOLE
<none></none>	<none></none>	6ec1ee5b654b	24 hours ago	17GB
<none></none>	<none></none>	074649510875	34 hours ago	17GB
<none></none>	<none></none>	0a94be34fc70	35 hours ago	1.96GB
<none></none>	<none></none>	1246a9fc57f3	35 hours ago	2.12GB
<none></none>	<none></none>	b83c4da03a05	35 hours ago	2.12GB
<none></none>	<none></none>	78d3dd107d39	36 hours ago	2.12GB
<none></none>	<none></none>	42e326facd59	36 hours ago	2.07GB
<none></none>	<none></none>	e8042c868182	36 hours ago	2.04GB
<none></none>	<none></none>	c1277f8fad24	36 hours ago	2.12GB
serenatto-chatbot	latest	06fff8904d08	36 hours ago	2.09GB
chatbot-bitdoglab_v2	latest	6889e315381a	43 hours ago	35.3GB
<pre>chatbot_bitdog_huggingface-chatbot</pre>	latest	8b7d63303b19	2 days ago	20.4GB
flask-app	latest	2d4ceec7bea9	2 weeks ago	1.49GB
ml-env	latest	7d89f3587381	2 weeks ago	1.64GB
hello-world	latest	7e1a4e2d11e2	3 months ago	20.4kB
PS D:\SENAI\2025-1\ChatBot\chatbot_api-agricola> docker run -p 8000:8000 -e GROQ_API_KEY=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 api_agro				







































Comando para exportar a imagem.tar docker save -o api_agro.tar api_agro

```
INFO:
          172.17.0.1:54882 - "POST /conversar HTTP/1.1" 200 OK
 INFO:
          172.17.0.1:35736 - "POST /conversar HTTP/1.1" 200 OK
                                                                                                                                                                                                                         ≥ docker
 INFO:
          172.17.0.1:50252 - "POST /conversar HTTP/1.1" 200 OK
 INFO:
          172.17.0.1:60902 - "POST /conversar HTTP/1.1" 200 OK
 INFO:
          Shutting down
 INFO:
          Waiting for application shutdown.
 INFO:
          Application shutdown complete.
          Finished server process [1]
 PS D:\SENAI\2025-1\ChatBot\chatbot api-agricola> docker ps
 CONTAINER ID IMAGE COMMAND CREATED STATUS PORTS
 PS D:\SENAI\2025-1\ChatBot\chatbot_api-agricola> docker save -o api_agro.tar api_agro [
                                                                                                                                                                   Ln 55, Col 42 Spaces: 4 UTF-8 CRLF {} Python 🔠 3.13.2 64-bit ⊘ Prettier
00 1 1 1 1 1 1
```

Obrigado!

Prof. Me Daniel Vieira

Email: danielvieira2006@gmail.com

Linkedin: Daniel Vieira

Instagram: Prof daniel.vieira95

